

XVA14


409 Stainless Steel Universal X-pipe Kit

XVA14: 3-1/2" Universal fit (Weld-in installation only)



Pypes Performance Exhaust
2705 Clemens Rd B103 Hatfield, PA 19440
www.pypesexhaust.com 800-421-3890

Thanks again for purchasing your new 409 stainless steel Pypes Performance Exhaust Universal X-pipe kit. Please be sure to confirm all the components in the kit were received in your shipment before beginning installation. This kit will include following components: (2) expanded front legs, (1) "X" center section and (2) rear legs. If you find any component missing, please contact our office at 800-421-3890 for replacement. Installation of this kit will require a few simple hand tools and a cutting device. For a quicker and tighter installation, welding of slip joints is recommended. Technical assistance is available both online at www.pypesexhaust.com or 800-421-3890.



1. This five piece kit is a universal kit produced to fit many applications. Measuring and cutting will be required. The x-pipe is designed to connect to your collector/reducers or down-pipes under the transmission cross-member.

2. Install the x-pipe. This is where trimming of the tubing may be required for the optimum fit. Install the rear legs into the mufflers first. You are aiming to have the center "X" land approx 8-12 inches behind the tail shaft of your transmission and centered under the driveshaft. Also, the center plate on the "X" has an arrow stamp which must point towards the engine. Trim the rear legs as needed to put your "X" and mufflers in the proper location. Quick tip: If the rear suspension is unloaded, you can push the center "X" up until it just about touches the drive shaft as it will not hit once the suspension is loaded. Slide the front legs into the x-pipe. They should end somewhere close to the humps in your transmission cross-member. On some applications, the front "X" legs may not be centered in the humps but line up to your headers or down-pipes. This is fine as the system will not hang too low. Be extra careful when measuring and cutting. A helpful tip: Line up the front legs under the center "X" to mark your cut lines making sure to line them up with you headers or down pipes. Some header applications require custom collectors due to the header not ending square and parallel to the car. For proper x- pipe fit, your collectors must run parallel with your rocker panels.

3. Finish the system by making all your final adjustments to position the x-pipe. This is a weld only kit. The 409 stainless can be welded with your standard mig welder, you just have to treat the welds.

(A) Center X
(B) Front Legs
(C) Rear Legs